

控制器 Controller

将空气开关关闭，切断电源

Turn off the air switch and turn off the power



用毛巾或抹布遮挡住前泥板烤漆部位

Use towels or wipes to shield the stoving varnish part of the front fender



用 T30 防盗梅花内六角扳手将螺丝拆掉

Remove the screws with T30 Allen wrench



拔下控制器接插件

Unplug the controller connector



用十字螺丝刀拆掉 5 颗螺丝拆下控制器

Remove the five screws with a Phillips screwdriver and remove the controller

