

后转向灯

用十字螺丝刀，拆下后尾灯 2 颗螺丝

Remove 2 screws from taillight with a Phillips screwdriver



拔下转向灯线束，14MM 扳手松开转向灯螺母，取下转向灯。

Unplug the wire harness of the turn signal, loosen the turn signal nut with a 14MM wrench, and remove the turn signal.

