

仪表总成 Instrument assembly

准备工作: Preparatory work:

拆下左车体上护罩-----见第二章 01 节

Remove the upper cover of the left body - See Section 01 of Chapter II

拆下左储物箱上护罩-----见第二章 02 节

Remove the upper cover of the left storage box - See Section 02 of Chapter II

拆下左储物箱装饰件-----见第二章 03 节

Remove the trim of the left storage box - See Section 03 of Chapter II


用 5mm 内六角拆下大灯两边螺栓、10mm 扳手拆下大灯底部螺丝,取下大灯总成

Remove the bolts on both sides of the headlamp with 5mm Allen wrench, remove the screw at the bottom of the headlamp with 10mm wrench, and then remove the headlamp assembly



用十字螺丝刀拆下仪表底壳 2 颗螺丝

Remove the two screws in the back shell of the instrument panel with a Phillips screwdriver



用 10MM 扳手拆下 2 颗仪表螺丝

Remove two screws on the instrument panel with a 10MM wrench



拨开仪表总成接插件、拔出仪表总成线束

Unplug the instrument assembly connector and unplug the instrument assembly harness

