

电池托盘 Battery tray

准备工作:

拆下左右车体上护罩-----见第二章 01 节

拆下左右储物箱上护罩-----见第二章 02 节

取出电池围仓-----见第二章 23 节

Preparatory work:


Remove the upper cover of left and right body - See Section 01 of Chapter II

Remove the upper cover of left and right storage boxes - See Section 02 of Chapter II

Remove the battery compartment - See Section 23 of Chapter II

用十字螺丝刀卸下左右两侧标记中四颗螺丝

Use a Phillips screwdriver to remove the four screws on the left and right sides as indicated in the figure



用十字螺丝刀卸下电池托盘四颗螺丝取出电池托盘

Remove the four screws of the battery tray with the Phillips screwdriver to remove the battery tray



