

电机总成 Motor assembly

准备工作:

拆下左车体上护罩-----见第二章 01 节

拆下左储物箱上护罩-----见第二章 02 节

拆下左储物箱装饰件-----见第二章 03 节

拆下车体左下护罩-----见第二章 26 节

Preparatory work:

Remove the upper cover of the left body - See Section 01 of Chapter II

Remove the upper cover of the left storage box - See Section 02 of Chapter II

Remove the trim of the left storage box - See Section 03 of Chapter II

Remove the lower cover of the left body - See Section 26 of Chapter II


用十字螺丝刀拆下控制器电机黄、绿、蓝三根相线

Remove the yellow, green and blue phase lines of the controller motor with a Phillips screwdriver




拔开电机霍尔线接头

Unplug the Hall line connector of the motor



12mm 套筒扳手卸下后刹车总成

Remove the rear brake assembly with a 12mm socket wrench



21mm 套筒扳手卸下电机左右两侧电机螺栓

用 10mm 扳手拆下电机左右定位片螺丝、拆下定位片

Remove the motor bolts on both sides of the motor with a 21mm socket wrench

Remove the left and right screws in the locating plate of the motor with a 10mm wrench and remove the locating plate



抽出电机线束、取下电机

Take out the motor harness and remove the motor

