

闪光灯继电器 Flash relay

准备工作:

拆下储物箱前罩-----见第二章 05 节

Preparatory work:

Remove the front cover of the storage box - See Section 05 of Chapter II

拔下接插件取出继电器更换

Unplug the connector and remove the relay for replacement

