

刹车泵注油 Brake pump oiling

用 T20 梅花内六角打开刹车泵三颗螺丝

Unscrew the three screws of the brake pump with the T20 torx screwdriver



已打开

Screws have been unscrewed



使刹车泵水平、根据刹车泵刻度注入适量（油量在 A-B 之间）的刹车油

Make the brake pump level, and inject appropriate amount of brake oil (between A and B) according to the brake pump scale

