

后尾灯

用十字螺丝刀，拆下后尾灯 2 颗螺丝

Remove 2 screws from taillight with a Phillips screwdriver



拔下后尾灯线束，取下后尾灯。

Unplug the rear taillight and remove the rear taillight.

