

制动碟拆卸 Disc brake disassembly

准备工作: Preparatory work

卸下前轮或后轮（后电机）-----见第二章 12 节或第一章 10 节

Remove the front wheel or rear wheel (rear motor) - See Section 12 of Chapter II, or Section 10 of Chapter I

用 6MM 内六角扳手将制动碟三颗固定螺栓卸下取下制动碟即可。

Remove the three fixing bolts of the disc brake with a 6MM Allen wrench and remove the disc brake.

注意：由于安装时制动碟螺丝经过加胶处理、拆卸螺丝时需注意、避免内六角螺栓打滑使拆卸人员受伤！

Note: As the disc brake screws have gone through the glue treatment during the installation, the disassembly personnel shall be careful when removing the screws to avoid injury caused by the slipping of the hexagon head bolt!