

## 储物箱前罩 **Front cover of the storage box**

准备工作:

拆下左右车体上护罩-----见第二章 01 节

拆下左右储物箱上护罩-----见第二章 02 节

拆下左右储物箱装饰件-----见第二章 03 节

Preparatory work:

Remove the upper cover of the left and right body - See Section 01 of Chapter II

Remove the upper cover of the left and right storage boxes - See Section 02 of Chapter II

Remove the trim of the left and right storage boxes - See Section 03 of Chapter II

用十字螺丝刀卸下储物箱前罩两侧固定螺丝

Use a Phillips screwdriver to remove the fixing screws  
on both sides of the front cover of the storage box



用十字螺丝刀卸下储物箱前罩两侧固定螺丝

取下储物箱前罩

Use a Phillips screwdriver to remove the fixing screws on both sides of the front cover of the storage box and remove the front cover of the storage box

---

