

## 喇叭 Speaker

准备工作:

拆下左车体上护罩-----见第二章 01 节

拆下左储物箱上护罩-----见第二章 02 节

Preparatory work:

Remove the upper cover of the left body - See Section 01 of Chapter II

Remove the upper cover of the left storage box - See Section 02 of Chapter II

用 10mm 开口扳手卸掉喇叭固定螺栓

Remove the fixing bolts of the speaker with a 10mm open-end wrench



拔掉喇叭 2 个接线插头

Unplug the two connection plugs of the speaker

