

## 刹车手柄 Front and rear brake handle

用 10mm 套筒加 10mm 扳手松开刹车手柄螺栓

Use a 10mm sleeve and a 10mm wrench to unscrew the bolt of the brake handle



取下手柄即可更换

Remove the handle to replace it

