

## 后视镜调节 Rearview mirror adjustment

首先把后视镜安装到固定位，调整好角度；

First install the rearview mirror to the fixed position and adjust the angle

---



14mm 开口扳手锁紧固定螺栓

Tighten the fixing bolt with a 14mm open-end wrench

---



扳动后视镜镜面调整好角度

Pull the rearview mirror to adjust the angle of the mirror

---

