

## 报警器 Alarm

准备工作：

拆下左车体上护罩-----见第二章 01 节

拆下左储物箱上护罩-----见第二章 02 节

拆下左储物箱装饰件-----见第二章 03 节

Preparatory work:

Remove the upper cover of the left body - See Section 01 of Chapter II

Remove the upper cover of the left storage box - See Section 02 of Chapter II

Remove the trim of the left storage box - See Section 03 of Chapter II

箭头指的部件就是报警器主机，用梅花螺丝刀即可拆卸下来

The component pointed by the arrow is the alarm host, which can be removed with a torx screwdriver

