


后碟刹 Rear disc brake

用 12MM 套筒扳手将刹车螺栓卸掉

Remove the brake bolts with a 12MM socket wrench



用尖嘴钳将刹车片卡销（2 个）取出

Remove the two block pins of the brake pad with needle nose pliers



按箭头方向取出刹车片插销

Remove the block pins of the brake pad in the direction of the arrow



按照箭头方向取下刹车片

Remove the brake pad in the direction of the arrow



将后刹车连接支架取出、然后将连接轴上加注黄油

Remove the attachment bracket of the rear brake and then **add butter** to the connecting shaft



安装后碟刹时现将连接板安装进制动钳上、再将大块刹车片套在连接轴上

When installing the rear disc brake, install the connecting plate on the brake caliper, and then install the large brake pad on the connecting shaft



按箭头方向将刹车片插销插紧

Push the plug pin of the brake pad in the direction of the arrow



按照红圈内方式、将卡销插入

Insert the block pin in the way as indicated in the red circle



将后碟刹放入安装位置、拧紧固定螺栓，捏几次刹车手柄就会恢复制动效果

Put the rear disc brake into the installation position, tighten the fixing bolts, and pinch the brake handle for several times to restore the braking effect

