

螺栓及螺帽力矩清单

Bolt and Nut Torque List

项目 Item	名称 Name	力矩 (N • m) Torque (N • m)
方向柱 Steering column	方向柱上螺帽 34MM 34MM upper nut of steering column	74
	方向把压块螺栓 Lock block bolt of handlebar	12
	前减震上联板 6MM 六角螺栓 6MM hexagon head bolt of upper yoke plate of front shock absorber	22
	前减震下联板 6MM 六角螺栓 6MM hexagon head bolt of lower yoke plate of front shock absorber	32
轮子 Wheel	前轮轴螺帽 Nut of front axle	59
	后轮电机轴两侧 21MM 螺帽 21MM nut on both sides of the motor shaft of rear wheel	80
	前后碟刹片 6MM 内六角螺栓 6MM hexagon head bolt of front and rear disc brakes	42
制动 Brake	前、后刹车手柄螺栓 Bolts of front and rear brake handles	10
	前、后制动手柄螺母 Nuts of front and rear brake handles	6
	前、后制动器螺栓 Bolts of front and rear brakes	26
大灯 Headlamp	支架总成螺栓 Bolts of bracket assembly	12
	大灯总成螺栓 Bolts of headlamp assembly	12
	调光螺栓 Dimming bolts	12
脚踏支架 Pedal bracket	脚踏螺栓 8MM 内六角 8MM hexagon head bolt of pedal	45
	脚踏中轴螺母	45

	Nut of pedal axle	
后减震	后减震 T50 梅花内六角螺栓 T50 torx hexagon head bolt of rear shock absorber	45
控制器	控制器 T30 梅花内六角螺栓 T30 torx hexagon head bolt of controller	12
支撑 Support	侧支撑螺母 Nut of side stand	45
开关 Switch	左、右组合开关总成螺栓 Bolts of left and right combination switch assembly	5
塑料件 Plastic parts	塑料件螺钉 Screw of plastic parts	4
	塑料件内六角螺栓 Hexagon head bolt in plastic parts	5

备注：紧固电机轴时先紧固制动侧螺母、再紧固另一侧螺母。

Note: When tightening the motor shaft, first tighten the nut on the brake side and then tighten the nut on the other side.