

## 大灯调节 Headlight adjustment

- A: 用 10mm 扳手松开（不必卸掉）大灯底部螺栓、
- B: 5mm 内六角扳手松开（不必卸掉）大灯两侧螺栓、
- C: 打开大灯上下调节灯光到合适的位置、拧紧即可

A: Unscrew the bolt at the bottom of the headlamp with a 10mm wrench (do not have to remove);

B: Unscrew the bolts on both sides of the headlamp with a 5mm Allen wrench (do not have to remove);

C: Open the headlamp to adjust the light to the appropriate location and tighten the bolts

