

## 前轮 Front wheel

### 准备工作: Preparatory work:

拆卸前轮需要准备架子把车子撑起来、以便前轮卸掉之后车子保持稳定。

It is necessary to prepare the support to hold up the car before removing the front wheels, so that the car can maintain stability after the front wheel is removed.

用 17mm 套筒扳手卡住前轮轴螺丝，14mm 扳手卡住螺丝对面、松开螺丝

Catch the screw of the front axle with a 17mm socket wrench and catch the opposite of the screw across with a 14mm wrench, to loosen the screw



螺丝松开后按照箭头方向抽出前轴、取下轮胎

After the screw is loosened, pull out the front axle in the direction of the arrow and remove the tire

