

12V 转换器

12V converter

准备工作:

拆下右车体上护罩-----见第二章 01 节

拆下右储物箱上护罩-----见第二章 02 节

拆下右储物箱装饰件-----见第二章 03 节

Preparatory work:

Remove the upper cover of the right body - See Section 01 of Chapter II

Remove the upper cover of the right storage box - See Section 02 of Chapter II

Remove the trim of the right storage box - See Section 03 of Chapter II

用梅花螺丝刀将图红圈中两个螺丝拆卸下

Remove the two screws (as indicated in the red circles) with a torx screwdriver



拔开转换器接插件

Unplug the converter connector



--