

## 侧支撑 Side stand

用尖嘴钳卸掉侧支撑弹簧

Remove the spring of the side stand with needle nose pliers



用十字螺丝刀松开侧支撑断电开关螺丝、取下断电开关

Use a Phillips screwdriver to loosen the power switch screw of the side stand and remove the power switch



卸掉侧支撑螺母, 松开旋转轴螺母取出螺母、取下侧支撑

Remove the side stand nut, loosen the rotary shaft nut to remove the nut, and remove the side stand

