

方向柱 Steering column

准备工作：Preparatory work:

拆卸前请准备支架把车体前部撑起。

Please prepare the support to hold up the front part of the body before disassembly

拆下前挡泥板-----见第二章 08 节

拆下大灯组合-----见第一章 01 节

拆下前轮-----见第二章 12 节

拆下前减震-----见第二章 13 节

拆下上联板-----见第二章 14 节

Remove the front fender - See Section 08 of Chapter II

Remove the headlamp combination - See Section 01 of Chapter I

Remove the front wheel - See Section 12 of Chapter II

Remove the front shock absorber - See Section 13 of Chapter II

Remove the upper yoke plate - See Section 14 of Chapter II

45-52 钩形扳手松开方向柱螺丝、取下方向柱。

Loosen the steering column screw with a 45-52mm claw wrench and remove the steering column.



取下方向柱

Remove the steering column

