

套锁更换 Lock replacement


整车套锁分为：坐垫锁、车头锁、电池锁

Car lock is divided into: cushion lock, front lock and battery lock

坐垫锁 Cushion lock


打开后坐垫、用十字起子按照箭头方向卸下坐垫锁卡子

Open the rear cushion and remove the cushion lock clamp with a Phillips screwdriver in the direction of the arrow



向外取出坐垫锁即可

Take out the cushion lock



电池锁 Battery lock


准备工作：Preparatory work:

卸下储物箱前罩-----见第二章 04 节

Remove the front cover of the storage box - See Section 04 of Chapter II


用十字螺丝刀卸下电池锁保护罩

Remove the battery lock cover with a Phillips screwdriver




用尖嘴钳拔出电池锁卡扣

Pull out the battery lock buckle with needle nose pliers



取出电池锁拉线柱，取出电池锁即可

Remove the terminal of the battery lock and remove the battery lock



车把锁 Handlebar lock

准备工作:


卸下方向柱-----见第二章 19 节

Preparatory work:

Remove the steering column - See Section 19 of Chapter II

用十字螺丝刀拆下车把锁两颗螺丝

Remove the two screws of the handlebar lock with a Phillips screwdriver



取下车把锁

Remove the handlebar lock

