

大灯总 Headlamp assembly

准备工作: Preparatory work:

拆下左车体上护罩-----见第二章 01 节

Remove the upper cover of the left body - See Section 01 of Chapter II

拆下左储物箱上护罩-----见第二章 02 节

Remove the upper cover of the left storage box - See Section 02 of Chapter II

拆下左储物箱装饰件-----见第二章 03 节

Remove the trim of the left storage box - See Section 03 of Chapter II

用 5mm 内六角拆下大灯两边螺栓、10mm 扳手拆下大灯底部螺丝

Remove the bolts on both sides of the headlamp with a 5mm hexagon, and remove the screw at the bottom of the headlamp with a 10mm wrench



拨开大灯接插件、剪断扎带拔出大灯线束

Unplug the headlamp connector and cut the cable tie to pull out the headlamp wiring harness

