

前制动器 Front brake

用 12mm 套筒扳手卸开图中前刹车制动器固定螺栓、即可取下制动器

Use a 12mm socket wrench to remove the fixing bolts of the front brake in the figure and remove the brake



用尖嘴钳将刹车片卡销（2 个）取出

Remove the two block pins of the brake pad with needle nose pliers



按箭头方向取出刹车片插销

Remove the block pins of the brake pad in the direction of the arrow



按照箭头方向取下刹车片

Remove the brake pad in the direction of the arrow



将后刹车连接支架取出、然后将连接轴上加注黄油

Remove the attachment bracket of the rear brake and then **add butter** to the connecting shaft



安装后碟刹时现将连接板安装进制动钳上、再将大块刹车片套在连接轴上

When installing the rear disc brake, install the connecting plate on the brake caliper, and then install the large brake pad on the connecting shaft



按箭头方向将刹车片插销插紧

Push the block pin of the brake pad in the direction of the arrow



按照红圈内方式、将卡销插入

Insert the block pin in the way as indicated in the red circle



将前碟刹放入安装位置、拧紧固定螺栓，反复捏几次刹车手柄就会恢复制动效果

Put the front disc brake into the installation position, tighten the fixing bolts, and pinch the brake handle for several times to restore the braking effect

