

左侧把套 Handlebar grip of the left side

手握住把套左右旋转并用力向外拔

Hold the handlebar grip, rotate it clockwise and anticlockwise and pull out it forcibly



拔出的把套

Pull out the handlebar grip

