

遥控器电池 Remote control battery

用钥匙对准遥控器顶部凹槽、轻轻向外撬动

Align the key to the groove at the top of the remote control and gently pry up the card slot



遥控器顶部卡槽撬出来后，沿着壳体周边将遥控器主体分离、

注意：分离时注意主体上的三个卡槽


After the card slot at the top of the remote control is pried up, separate the main body of the remote control along the periphery of the shell

Note: Pay attention to the three card slots on the main body during the separation



完全分离后打开壳体

Open the shell after the main body is completely separated



将遥控器主板取出、反过来即可看见电池，按照电池规格更换全新电池

Remove the mainboard of the remote control, turn over the mainboard, and then you can see the battery. Replace the new battery in accordance with the battery specifications.



将遥控器主板放入壳体、将按键部分对准卡槽装入即可

Put the mainboard of the remote control into the shell and note that the button shall be aligned to the card slot

