

## 电池 Battery

钥匙顺时针打开储物箱上盖

Turn the key clockwise to open the cover of the storage box



取出储物箱盖内衬板

Remove the interior lining panel in the storage box cover



关闭空气开关

Turn off the air switch



拔下电源线插头、顺时针拧开电池钥匙、向上取出电池组

Unplug the power cord, unscrew the battery key clockwise, and remove the battery pack upwards

---

