

右开关组合总成

Right switch combination assembly

准备工作:

拆下左车体上护罩-----见第二章 01 节

拆下左储物箱上护罩-----见第二章 02 节

拆下左储物箱装饰件-----见第二章 03 节

Preparatory work:

Remove the upper cover of the left body - See Section 01 of Chapter II

Remove the upper cover of the left storage box - See Section 02 of Chapter II

Remove the trim of the left storage box - See Section 03 of Chapter II

用十字螺丝刀拆下右边开关组合 2 颗螺丝 (图标记处)

Remove the two screws in the right switch combination (as indicated) with a Phillips screwdriver



拨开右开关组合总成接插件、拔出线束

Unplug the right switch combination assembly connector and pull out the harness



