

## 后减震 Rear shock absorber


用 5mm 内六角扳手卸下后挡泥板左侧 2 颗螺栓，10mm 扳手卸下挡泥板支架固定螺栓

Remove the 2 screws on the left side of the rear fender with a 5mm Allen wrench, and Remove fender bracket retaining bolt with 10mm wrench



用 5mm 内六角扳手卸下后挡泥板右侧 2 颗螺栓，10mm 扳手卸下挡泥板支架固定螺栓

Remove the 2 screws on the right side of the rear fender with a 5mm Allen wrench, and Remove fender bracket retaining bolt with 10mm wrench



用 T50 梅花内六角扳手卸下后减震两颗螺栓、拆下减震即可。

Remove the two bolts of the rear shock absorber with a T50 torx wrench and remove the rear shock absorber.

