

右车体上护罩 Upper cover of the right body

左车体上护罩同样的步骤

Same as the steps in the upper cover of the left body

用 5mm 的内六角扳手将红圈中三个螺丝拆卸下来、取下护罩

Use a 5mm Allen wrench to remove the three screws in the red circles and remove the cover

