

左、右储物箱上护罩 Upper covers of the left and right storage boxes

左储物箱上护罩的拆卸同样顺序

Same as the steps for the removal of the upper cover of the left storage box

用 5mm 的内六角扳手将红圈中三个螺丝拆卸下来、取下护罩

Remove the three screws in the red circles with a 5mm Allen wrench and remove the cover



用梅花螺丝刀将图中两个螺丝拆卸下取下储物箱右罩

Remove the two screws in the figure with a torx screwdriver and remove the right cover of the storage box



用梅花螺丝刀将红圈中两个螺丝拆卸下

Remove the two screws in the red circles with a torx screwdriver



注意箭头所指卡扣方向，先向上，再向外，将储物箱右装饰盖取出

Note the direction of the buckle pointed by the arrow. Pull the buckle first upward and then outward to remove the right decorative cover of the storage box

