

## 前挡泥板 Front fender

用 5mm 内六角扳手卸下前挡泥板红圈内左、右各三颗螺丝  
即可取下前挡泥板

Remove the three screws in the red circles respectively on the left  
and right sides of the front fender with a 5mm Allen wrench to  
remove the front fender

