

脚蹬调节 Pedal adjustment

用 8MM 内六角扳手将左固定脚踏支架下面一颗螺丝拧松，将螺栓卸掉。

Unscrew a screw below the left fixed pedal bracket with an 8mm Allen wrench and remove the bolt



用 8MM 内六角扳手将右固定脚踏支架下面一颗螺丝拧松，将螺栓卸掉。

Unscrew a screw below the right fixed pedal bracket with an 8mm Allen wrench and remove the bolt



脚踏是由下端螺栓定位在车架定位孔中，如图所示

The pedal is positioned in the frame positioning hole by the lower bolt, as shown in the figure



如图所示，拆除固定螺栓后就能随意调整脚踏高度，找到适合您的角度后将螺栓安装牢固即可

As shown in the figure, after removing the fixing bolts, you can adjust the pedal height. Install and fix the bolt after you adjust the pedal to the appropriate position

