

后减震调节 Rear shock absorber adjustment

45-52MM 勾型扳手 2 把

Two 45-52mm claw wrenches



减震调节螺丝由两个螺丝固定，靠下方的螺丝要逆时针拧松，上面的螺丝要顺时针用力固定住

The shock absorber is fixed by two screws. The lower screw shall be unscrewed counterclockwise and the upper screw shall be fixed clockwise



上面的螺丝用勾型扳手向下用力固定住（顺时针方向）

Tighten the upper screw with a claw wrench firmly (clockwise)



下面的螺丝按箭头方向，向下用力，直到拧松（逆时针方向）

Unscrew the lower screw in the direction of the arrow
(counterclockwise)



如图所示，两个勾型扳手同时用力，将减震调节螺丝拧松，
再来调节后减震螺丝位置

As shown in the figure, unscrew the adjusting screws of the shock
absorber with two claw wrenches at the same time and then adjust the
screw position of the rear shock absorber




减震下端螺栓拧松后再拧上端螺丝调节

Unscrew the bolt at the lower end of the shock absorber and then
loosen the screw at the upper end to adjust



如图所示，按照需求调整减震软硬

As shown in the figure, adjust the shock absorber as required



用两个勾型扳手，上端螺丝逆时针方向固定住，下端螺丝顺时针方向用力拧紧即可

Use two claw wrenches to fix the upper screw counterclockwise and tighten the lower screw clockwise

