

## 后轮胎 Rear tires

准备工作:


取下电机----见第一章 10 节

Preparatory work:

Remove the motor - See Section 10 of Chapter I


将电机从车上完整拆卸下来

Remove the motor from the car




卸掉气门芯放掉，从轮胎边缘将轮胎挤压至轮圈中心位置

Remove the valve core to release the air and extrude the tire from the tire edge to the center of the rim



从轮胎另一边的边缘将轮胎挤压至轮圈中心位置

Extrude the tire from the tire edge of the other side to the center of the rim



用撬胎扁棍将轮胎从轮圈上卸下，类似于更换汽车轮胎

The tires are removed from the rims with a tyre lever, similar to the replacement of car tires

