

# 方向把 Handlebar

## 准备工作

卸下右组合开关总成-----见第一章 03 节

卸下左组合开关总成-----见第一章 04 节

拔下左侧把套-----见第二章 26 节

卸下前制动上泵总成；卸下后制动上泵总成

## Preparatory work

Remove the right combination switch assembly - See Section 03 of Chapter I

Remove the left combination switch assembly - See Section 04 of Chapter I

Unplug the handlebar grip of the left side - See Section 26 of Chapter

Remove the front and rear brake upper pump assembly

用 5MM 内六角扳手将方向把管压块四颗螺丝卸下

取下方向把

Remove the four screws of the handlebar stem block with a 5mm Allen wrench and remove the handlebar

