

## 左、右前脚踏支架拆卸 Left and right pedal disassembly

用 8MM 内六角扳手将图中标识中脚蹬两颗螺栓卸掉  
即可取下前脚踏

Remove the two bolts of the pedal indicated in the figure  
with an 8mm Allen wrench and remove the pedal

