

前减震 Front shock absorber

准备工作：

拆卸前轮需要准备架子把车子撑起来、以便前轮卸掉之后车子保持稳定.

卸下两侧大灯支架-----见第二章 12 节

卸下前挡泥板-----见第二章 08 节

卸下前碟刹-----见第二章 07 节

卸下前轮-----见第二章 13 节

Preparatory work:

It is necessary to prepare the support to hold up the car before removing the front wheels, so that the car can maintain stability after the front wheel is removed.

Remove the headlamp brackets of both sides - See Section 12 of Chapter II

Remove the front fender - See Section 08 of Chapter II

Remove the front disc brake - See Section 07 of Chapter II

Remove the front wheel - See Section 13 of Chapter II

用 6mm 内六角扳手将前减震上联板左右两侧两颗固定螺丝
松开

Unscrew the two fixing screws on the two sides of the upper
yoke plate of the front shock absorber with a 6mm Allen wrench



用 6mm 内六角扳手将前减震下联板左右两侧两颗固定螺丝松开

Unscrew the two fixing screws on the two sides of the lower yoke plate of the front shock absorber with a 6mm Allen wrench



向下抽出减震

Pull out the shock absorber downward

