

## 工具 Tools

装配及调试所需工具: Tools required for assembly and debugging:

名称 Name	规格 Specifications	作用 Role
开口扳手 Open-end wrench	10mm	喇叭; 仪表、大灯 Speaker, instrument, headlamp
开口扳手 Open-end wrench	12mm	过油螺栓 Hollow bolt
开口扳手 Open-end wrench	14mm	转向灯、后视镜 Turn signal lamp, rearview mirror
特殊工具 Special tools		
套筒扳手 Socket wrench	8mm	前、后刹车油泵总成 Front and rear brake oil pump assemblies
套筒扳手 Socket wrench	10mm	刹车手柄、 Brake handle
套筒扳手 Socket wrench	12mm	前、后制动总成 Front and rear brake assemblies
套筒扳手 Socket wrench	14mm	脚踏中轴、侧支撑 Pedal axle, side stand
套筒扳手 Socket wrench	21mm	前轮胎中轴、电机 Front tire axle, motor
套筒扳手 Socket wrench	34mm	方向柱螺母 Nut of steering column
内六角扳手 Allen wrench	3mm	大灯支架 Headlamp bracket
内六角扳手 Allen wrench	5mm	前、后挡泥板; 左右车体上护罩; 大灯 Front and rear fender; upper cover of the left and right body; headlamp
内六角扳手 Allen wrench	6mm	前碟刹盘; 后碟刹盘 Front disc brakes; rear disc brakes
内六角扳手 Allen wrench	8mm	调整脚踏 Adjusting pedal
十字螺丝刀 Phillips screwdriver	#1	转把 Handlebar
十字螺丝刀 Phillips screwdriver	#2	塑件 Plastic parts
十字螺丝刀 Phillips screwdriver	#3	塑件 Plastic parts
梅花内六角 Torx screwdriver	T20	刹车泵 Brake pump
梅花内六角扳手	T30	控制器

Torx screwdriver		Controller
梅花内六角扳手 Torx screwdriver	T50	后减震、副车架 Rear shock absorber, auxiliary frame
钩形扳手 Claw wrench	45-52mm	后减震调节、方向柱八件碗螺丝 Rear shock absorber adjustor, screws of the head parts of the steering column
尖嘴钳 Needle nose pliers		前、后制动蹄块 Front and rear brake shoes