

启动按键组合 Start button combination

准备工作:

拆下左右两侧车体上护罩-----见第二章 01 节

拆下左右两侧储物箱罩-----见第二章 02 节

拆下左右两侧储物箱装饰件-----见第二章 03 节

拆下储物箱前罩-----见第二章 5 节

Preparatory work:

Remove the upper covers on the left and right sides of the body - See Section 01 of Chapter II

Remove the left and right covers of the storage box - See Section 02 of Chapter II

Remove the trims on the left and right sides of the storage box - See Section 03 of Chapter II

Remove the front cover of the storage box - See Section 05 of Chapter II

拔开启动按键组合插头

Unplug the start button combination plug



松开启动按钮固定螺丝、拆下启动按钮

Unscrew the fixing screw of the start button and remove the start button

